

VORTAC PKE	APP CRS	Rwy Idg	N/A
117.9	067°	TDZE	N/A
Chan 126		Apt Elev	458

VOR/DME-A

AVI SUQUILLA (P20)

V

NA

When local altimeter setting not received, use Blythe altimeter setting and increase all MDA 100 feet.

MISSED APPROACH: Climbing left turn to 5000 direct PKE VORTAC and hold.

AWOS-3PT	LOS ANGELES CENTER	UNICOM
132.75	128.15 285.6	122.725 (CTAF) 0

