

|               |         |          |      |
|---------------|---------|----------|------|
| LOC/DME I-OJW | APP CRS | Rwy Idg  | 5700 |
| 108.3         | 183°    | TDZE     | 54   |
| Chan 20       |         | Apt Elev | 56   |

LDA RWY 20R

JOHN WAYNE/ORANGE COUNTY (SNA)

|                                                                                                                                   |                                     |                                                                                             |
|-----------------------------------------------------------------------------------------------------------------------------------|-------------------------------------|---------------------------------------------------------------------------------------------|
| DME required.                                                                                                                     | MALSR                               | MISSED APPROACH: Climb to 1000 then climbing right turn to 3000 direct SLI VORTAC and hold. |
| <div><div></div><div>◀ Circling Rwy 20L NA at night. For inop ALS, increase S-LDA 20R Cat C/D visibility to RVR 6000.</div></div> | <div><div></div><div>A5</div></div> |                                                                                             |

|        |               |                        |         |          |       |        |
|--------|---------------|------------------------|---------|----------|-------|--------|
| D-ATIS | SOCAL APP CON | JOHN WAYNE TOWER ★     | GND CON | CLNC DEL | CPDLC | UNICOM |
| 126.0  | 121.3 263.1   | 126.8 (CTAF) 0 343.625 | 120.8   | 118.0    |       | 122.95 |

