

ILS or LOC RWY 26L
ONTARIO INTL (ONT)

MISSED APPROACH: Climb to 2800 then climbing left turn to 5400 direct PDZ VORTAC and hold. continue climb-in-hold to 5400.

Rwy 26R

Procedure NA for arrival on PDZ VORTAC airway radials 012 CW 078.

ONTARIO INTL (ONT)
ILS or LOC RWY 26L