

18200 **AIRPORT DIAGRAM** BALTIMORE/WASHINGTON INTL THURGOOD MARSHALL (BWI) BALTIMORE, MARYLAND

AL-804 (FAA)

BALTIMORE, MARYLAND

D-ATIS
115.1 127.8
BALTIMORE TOWER
119.4 257.8
GND CON
121.9
CLNC DEL
118.05
CPDLC


324 A

JANUARY 2015
ANNUAL RATE OF CHANGE
0.0° W

RWY 10-28
PCN 105 F/A/W/T
S-80, D-220, 2D-1020, 2D/2D2-1340
RWY 15L-33R
PCN 15 F/A/W/T
S-30, D-45
RWY 15R-33L
PCN 70 F/A/W/T
S-80, D-220, 2D-675, 2D/2D2-890

NE-3, 31 JAN 2019 to 28 FEB 2019

NE-3, 31 JAN 2019 to 28 FEB 2019



ASDE-X in use. Operate transponders with altitude reporting mode and ADS-B (if equipped) enabled on all airport surfaces.

Runway Status Lights in operation.

**CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.**

