

AIRPORT DIAGRAM

BIRMINGHAM-SHUTTLESWORTH INTL (BHM)
AL-50 (FAA) BIRMINGHAM, ALABAMA

ATIS 119.4 270.1
BIRMINGHAM TOWER 119.9 317.725
GND CON 121.7 348.6
CLNC DEL 125.675 305.2


D

RWY 06-24
PCN 65 F/C/X/T
S-175, D-205, 2D-350
RWY 18-36
PCN 45 F/C/X/T
S-75, D-170, 2D-240

33°35'N
33°34'N
33°33'N
JANUARY 2020
ANNUAL RATE OF CHANGE
0.1° W

SE-4, 11 JUL 2024 to 08 AUG 2024

SE-4, 11 JUL 2024 to 08 AUG 2024



CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.

AIRPORT DIAGRAM

BIRMINGHAM, ALABAMA
BIRMINGHAM-SHUTTLESWORTH INTL (BHM)